



# RADE KONČAR KONTAKTORI I RELEI D.O.O.

INSTRUCTIONS FOR USE / UPUTSTVO ZA UPOTREBU / УПАТСТВО ЗА УПОТРЕБА

ROTARY CAM SWITCHES / BREGASTE SKLOPKE / БРЕГАСТИ СКЛОПКИ



Series: BS ...  
Serija: BS ...  
Серија: BS ...



Version: "PS"  
Verzija: "PS"  
Верзија: "PS"



Version: "LK"  
Verzija: "LK"  
Верзија: "LK"




Version: "ES"  
Verzija: "ES"  
Верзија: "ES"





Type/Tip/Тип  
BSB 16 ...  
BSB 25 ...


IEC 60947-3  
VDE 0660  
EN 60947-3




Front mounting /  
Ugradna sklopka /  
Предна монтажа:  
"U"




Rear mounting /  
Odvojena ugradnja/  
Задна монтажа:  
"O"




"BS ..."




"PS"



"LK"



Assembly of BSB ...  
Montaža BSB-a ...  
Монтажа на BSB ...



Drilling plan (mm) / Plan bušenja (mm) / План за бушење (mm)

















Type/ Tip/Тип	a	b	c	d	e	e'	f	g	Torque / Moment/ Момент
BS 16	36	58*	48*	10	4,2	4,2	3,2	36	1,2 Nm
BS 25		58**	48**	30					
BS 32		58	48					48	1,2 Nm
BS 40		85*	68-74*	10	4,2	5,3*		58	1,8 Nm
BS 63		58	48	10	4,2	4,2		48 58	2 Nm
BS 80/100								68/85	2,5 Nm
BS 120/160		85	68-74	14	5,3	5,3			4 Nm
BSB 16									
BSB 25	36			10	4,2	4,2		36	1,2 Nm



BS 16 ... L  
BS 25 ... L  
(max. up to 4 elements/  
max. do 4 elelemenata/  
макс. до 4 елемента)

\*) Only for BS .. U A Version /  
Samo za BS .. U A Verziju /  
Само за BS .. U A Верзијата  
\*\*) Only for BS 25 .. U A and LK Version /  
Samo za BS 25 .. U A i LK Verziju /  
Само за BS 25 .. U A i LK Верзијата

No. of diagram / Broj šeme / Број на шемата



**RADE KONČAR KONTAKTORI I RELEI D.O.O.**

1000 - Skopje, Macedonia, III Makedonska brigada br. 54

Tel./Fax: ++389 (0)2/ 2461-106; 2465-586; 2463620; 2463-596

E-mail: marketing@radekoncar.com.mk, E-mail: export@radekoncar.com.mk,

E-mail: prodaja@radekoncar.com.mk

http://www.radekoncar.com.mk